

HEAVY DUTY PADS



WS3186
Mercedes Sprinter
(208D;308D)
& Vito (108;114) Front



WS3188
Mercedes Sprinter Rear
(308D;310D;312D;314)



WS3211
Mercedes Sprinter &
Vito Rear (208;211;212;
214;308;311;312)



WS5012
MAN F90, F2000 &
M2000 (F), TG (F+R)



WS5013
Mercedes
Actross



WS5014
MAN M2000 (F+R)
& MAN U90 Bus (F+R)



WS5015
ATEGO WITH KNORR /
PERROT BRAKES



WS5016
Iveco Eurocargo
Front & Rear



WS5032
MAN TG-L Front &
Mercedes Atego (F+R)

